05BBL–02

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
ES starting system does not operate	1. ES start switch	05–301
	2. Parking brake switch	05–301
	3. Skid control ECU	05–301
	4. Power source circuit	05–301
	5. Vehicle speed sensor	05–301
	6. Wire harness	
ES buzzer does not sound	1. ES start buzzer	05–306
	2. Skid control ECU	05–306
	3. Wire harness	