



INSPECTION

1. **M/T:**
INSPECT BACK-UP LIGHT SWITCH CONTINUITY

Switch position	Specified condition
Push	Continuity
Free	No continuity

If continuity is not as specified, replace the switch.

2. **A/T:**
INSPECT PARK/NEUTRAL POSITION SWITCH CONTINUITY (See page [DI-189](#))