



CIRCUIT



BODY ELECTRICAL - COMBINATION METER



P

I12362

No.	Wire Harness Side	
A	1 DOME Fuse	
	2 GAUGE Fuse	
	3 O/D Off Switch	
	4 Headlight Dimmer Switch	
	5 Starter Relay	
	6 Turn Signal Switch (Right)	
	9 Window Washer Level Warning Switch	
	11 Driver's Buckle Switch	
	12 Driver Door Courtesy Switch	
	13 Except Driver Door Courtesy Switch	
	14 Ground	
	17 Ground	
	18 Fuel Sender Gauge	
	19 Speed Control Unit	
	20 Vehicle Speed Sensor (SI terminal)	
	21 Key Unlock Warning Switch	
	22 Passenger's Buckle Switch	
	B	2 Light Control Rheostat Volume
		4 Light Control Switch
		5 ECM
		6 ECM
		7 Low Oil Pressure Warning Switch
8 ECM		
11 Vehicle Speed Sensor (SE terminal)		
12 Ignition Switch		
13 Generator		
14 Airbag Sensor Assembly		
15 Brake Fluid Level Warning Switch		
16 Turn Signal Switch (Left)		
17 ABS ECU		
18 Passenger's Seat Belt Warning		