



REASSEMBLY

1. COAT PISTON WITH LITHIUM SOAP BASE GLYCOL GREASE, AS SHOWN
2. INSTALL PISTON WITH SPRING INTO CYLINDER
3. INSTALL BOOT WITH PUSH ROD TO CYLINDER
4. INSTALL UNION AND 2 NEW GASKETS WITH UNION BOLT
Torque: 24.5 N·m (250 kgf·cm, 18 ft·lbf)
5. INSTALL BLEEDER PLUG
Torque: 8.4 N·m (85 kgf·cm, 74 in·lbf)