

(Cont. next page)

Engine Control (2GR–FE)




* 1 : w/ Power Switch
* 2 : w/o Power Switch
* 8 : Before Dec. 2008 Production
* 9 : From Dec. 2008 Production
*11 : RHD From Dec. 2008 Production
*12 : Except RHD From Dec. 2008 Production
*13 : Before Dec. 2008 Production, RHD From Dec. 2008 Production until May 2016 Production
*14 : Before Jun. 2010 Production
*15 : From Jun. 2010 Production
*17 : Before Apr. 2012 Production
*19 : Before May 2016 Production
*20 : From May 2016 Production
*21 : From Apr. 2012 Production until May 2016 Production
*25 : LHD From Dec. 2008 Production until May 2016 Production

(Cont. next page)




(Cont. next page)

Engine Control (2GR–FE)




(Cont. next page)



(Cont. next page)


ECT and A/T Indicator (2GR–FE)



∗1 : w/ Power Switch
∗2 : w/o Power Switch
∗6 : w/ Power Rear No. 2 Seat with Stowing Function
∗7 : w/ Parking Assist (TOYOTA Parking Assist–Sensor)
∗8 : Before Dec. 2008 Production
∗9 : From Dec. 2008 Production
∗10 : LHD From Dec. 2008 Production
∗11 : RHD From Dec. 2008 Production
∗12 : Except RHD From Dec. 2008 Production
∗20 : From May 2016 Production
∗22 : RHD From Dec. 2008 Production until May 2016 Production
∗23 : RHD ∗20
∗24 : Except ∗23

(Cont. next page)

ECT and A/T Indicator (2GR–FE)



38 PREVIA / TARAGO (Cont' d)

ECT and A/T Indicator (2GR–FE)

∗20 : From May 2016 Production
∗23 : RHD ∗20

