
F RELAY LOCATIONS


② : Engine Room R/B No.2 ⬭ : Engine Room J/B No.2	Engine Compartment Right (See Page 20)

* 1:20A FOG (Before Apr. 2012 Production)
  15A FOG (From Apr. 2012 Production until May 2016 Production,
  From May 2016 Production w/o Daytime Running Light)
  7.5A DRL (w/ Daytime Running Light)
* 2:DRL Relay (w/ Daytime Running Light)
  FOG Relay (w/o Daytime Running Light)



(2GR-FE General, 2GR-FE Middle East, 2GR-FE Australia Towing Package, 2GR-FE From Jun. 2007 Production Australia Except Towing Package)

Unit B




F RELAY LOCATIONS

② : Engine Room R/B No.2 ⬭ : Engine Room J/B No.2	Engine Compartment Right (See Page 20)


(2GR-FE Before Jun. 2007 Production Australia Except Towing Package)

Unit B



(2AZ-FE)

Unit B


FAN NO.1 Relay
FAN NO.3 Relay
FAN NO.2 Relay
H-LP Relay
DIM Relay
50A CDS FAN
(for High Current)
50A RDI FAN
(for High Current)
H-LP LH
15A
H-LP RH
15A
H-LP LL
15A
H-LP RL
15A