

## F RELAY LOCATIONS

| : Instrument Panel J/B LH | Left Side of the Instrument Panel (See Page 21) |
|---|---|




View A


1 15
2 16
3 17
4 18
5 19
6 20
7 21
8 22
9 23
10 24
11 25
12 26
13 27
14 28
4A
15 1
16 2
17 3
18 4
19 5
20 6
21 7
22 8
23 9
24 10
25 11
26 12
27 13
28 14
(from Instrument Panel Wire)
1 17
2 18
3 19
4 20
5 21
6 22
7 23
8 24
9 25
10 26
11 27
12 28
13 29
14 30
15 31
16 32
4D
17 1
18 2
19 3
20 4
21 5
22 6
23 7
24 8
25 9
26 10
27 11
28 12
29 13
30 14
31 15
32 16
(from Instrument Panel Wire)

## F RELAY LOCATIONS


| : Instrument Panel J/B LH | Left Side of the Instrument Panel (See Page 21) |
|---|---|

**(Before May 2016 Production)**



## (From May 2016 Production)

View B



## F RELAY LOCATIONS

| : Instrument Panel J/B LH | Left Side of the Instrument Panel (See Page 21) |
|---|---|

View C

* 1:7.5A STP RR (Before May 2016 Production)
  7.5A STOP LP NO.1 (From May 2016 Production)
* 2:7.5A STP HI MT (Before May 2016 Production)
  7.5A STOP LP NO.3 (From May 2016 Production)
* 3:7.5A STP RL (Before May 2016 Production)
  7.5A STOP LP NO.2 (From May 2016 Production)

