
REAR FLOOR PAN TO QUARTER PANEL EXTENSION (ASSY)



F25307A

Symbol meaning

REMOVAL	▲ : Remove Weld Points
INSTALLATION	■ : Plug Weld

F44970B

REMOVAL·INSTALLATION



F25307

INSTALLATION POINT

1 After welding, apply body sealer to the corresponding parts. (See the paint·coating)
2 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.