

Headlight Beam Level Control
* 1 : Before Aug. 2009 Production
* 2 : From Aug. 2009 Production
* 3 : Before Nov. 2010 Production
* 4 : From Nov. 2010 Production
1
2
3
4
10A HEAD (LO LH) (*3)
10A HEAD (LO RH) (*4)
HEAD Relay
Battery
A34 Headlight Leveling Motor RH (Headlight Assembly RH)
E74 Headlight Leveling Switch
A37 Headlight Leveling Motor LH (Headlight Assembly LH)
A29(A), A30(B) Junction Connector
RHB1
RHE
RHM+
B
RHO
E
LHO
LHB1
LHM
LHE
L–O
W–B
L
R
R–L
(*3)
(*4)
(*1)
(*2)
31 EA4
29 EA4
35 EA4
18 EA1
34 EA4
A1