

(Cont. next page)



(Cont. next page)

Engine Control (From Aug. 2014 Production)


∗ 3 : w/ Air Injection Control Driver
∗ 4 : w/o Air Injection Control Driver



(Cont. next page)

Engine Control (From Aug. 2014 Production)


∗ 3 : w/ Air Injection Control Driver
∗ 4 : w/o Air Injection Control Driver



(Cont. next page)

Engine Control (From Aug. 2014 Production)


* 1 : Shielded
* 3 : w/ Air Injection Control Driver
* 4 : w/o Air Injection Control Driver



(Cont. next page)

Engine Control (From Aug. 2014 Production)


* 1 : Shielded
* 3 : w/ Air Injection Control Driver
* 4 : w/o Air Injection Control Driver



(Cont. next page)

ECT and A/T Indicator (From Aug. 2014 Production)


* 1 : Shielded
* 2 : w/ Cruise Control



(Cont. next page)

Cruise Control (From Aug. 2014 Production)


＊2 : w/ Cruise Control
＊3 : w/ Air Injection Control Driver
＊4 : w/o Air Injection Control Driver
＊5 : LHD A/T
＊6 : RHD



(Cont. next page)

Cruise Control (From Aug. 2014 Production)

* 3 : w/ Air Injection Control Driver
* 4 : w/o Air Injection Control Driver
* 5 : LHD A/T
* 6 : RHD



Cruise Control (From Aug. 2014 Production)

