

(Cont. next page)

Turn Signal and Hazard Warning Light




Turn Signal and Hazard Warning Light
5
6
7
8
E9
Turn Signal Flasher
LL
LR
HAZ
∗5 : w/ Rear Fog Light
∗6 : w/o Rear Fog Light
∗7 : Before Nov. 2010 Production
∗8 : From Nov. 2010 Production
∗9 : Before Aug. 2012 Production
∗10 : From Aug. 2012 Production
Main Body ECU
<8–27><29–27>
A/C Amplifier
<24–11>
L12
Rear Combination Lamp (LH)
L15
Rear Combination Lamp (RH)
L21(A), L22(B)
Junction Connector
N3
Rear Turn Signal Light LH
(Rear Light Assembly LH)
N2
Rear Turn Signal Light RH
(Rear Light Assembly RH)
Turn
L1
L2