



B19
B17
B18
B20
B21
B5
B23
B9
B22
B8
B24
B6
B14
B10
B7
B11
B16
B13
B15
B12
B25

B 5 Ignition Coil (No.5)
B 6 Ignition Coil (No.3)
B 7 Ignition Coil (No.1)
B 8 Noise Filter (Ignition)
B 9 Fuel Injector (No.5)
B 10 Fuel Injector (No.3)
B 11 Fuel Injector (No.1)
B 12 Camshaft Timing Oil Control Valve (RH)
B 13 Air Flow Meter
B 14 Throttle Body Assembly
B 15 VVT Sensor (Bank 1)
B 16 Power Steering Oil Pressure SW
B 17 VSV (ACIS)
B 18 Fuel Injector (No.6)
B 19 Water Temp. Sensor
B 20 Ignition Coil (No.6)
B 21 Fuel Injector (No.4)
B 22 VSV (Purge)
B 23 Ignition Coil (No.4)
B 24 Ignition Coil (No.2)
B 25 Fuel Injector (No.2)


B 5
Black



B 6
Black




B 7
Black




B 8
Gray




B 9
Gray



B 10
Gray




B 11
Gray




B 12
Black




B 13
Black



B 14
Black




B 15
Black




B 16
Black



B 17
Brown




B 18
Gray




B 19
Gray




B 20
Black




B 21
Gray




B 22
Gray



B 23
Black



B 24
Black



B 25
Gray

