



A46
A45
A14
A5
A11
A4
A36
A12
A33
A8
A31
A29
A44
A28
A20
A30
A38
A16
A34
A32
A24
A40
A19
A18
A17
A39
A35
A23
A37

A 4 Skid Control ECU with Actuator
A 5 Skid Control ECU with Actuator
A 8 Option Connector (Driving Lamp)
A 11 Windshield Wiper Motor
A 12 Wireless Door Lock Buzzer
A 14 Brake Fluid Level Warning SW
A 16 Turn Signal and Clearance Lamp (Front LH)
A 17 Horn
A 18 Ambient Temp. Sensor
A 19 Pressure SW
A 20 Turn Signal and Clearance Lamp (Front RH)
A 23 Headlamp (LH)
A 24 Headlamp (RH)
A 28 Junction Connector
A 29 Junction Connector
A 30 Junction Connector
A 31 Option Connector (Horn)
A 32 Clearance Light RH (Headlight Assembly RH)
A 33 Side Turn Signal Light Assembly RH
A 34 Headlight Leveling Motor RH (Headlight Assembly RH)
A 35 Clearance Light LH (Headlight Assembly LH)
A 36 Side Turn Signal Light Assembly LH
A 37 Headlight Leveling Motor LH (Headlight Assembly LH)
A 38 Windshield Washer Motor
A 39 Airbag Sensor (Front LH)
A 40 Airbag Sensor (Front RH)
A 44 Air Pump Assembly
A 45 Air Injection Control Driver
A 46 Air Injection Control Driver


A4
Black



A5
Black



A8
Gray




A11
Black



A12
Black



A14
Gray



A16
Gray




A17
Black



A18
Black




A19
Gray




A20
Gray




A23
Black




A24
Black




A28
White



A29
Blue




A30
Blue



A31
Black



A32
Brown




A33
Gray



A34
Black



A35
Brown



A36
Gray



A37
Black



A38
Gray




A39
Yellow




A40
Yellow



A44
Black



A45
Black



A46
Black

