



Skid Control Sensor
Front RH Wire
BU1
Skid Control Sensor
Front LH Wire
AB2
AV1
BD1
Differential
Wire
AW1
CA2
Engine
No.2 Wire
Af1
Engine Room
Main Wire
Engine Room
No.3 Wire
Engine Wire
Sensor Wire


AB1
Gray




AB2
Black




AV1
Gray




AW1
Gray




Af1
Gray



BD1
Gray



BU1
Dark Gray



CA2
Gray

