


* 2:Before Aug. 2012 Production
* 3:From Aug. 2012 Production

A 1 Ignition SW
A 2 Accelerator Position Sensor
A 3 Stop Lamp SW
A 41 Junction Connector
A 42 Junction Connector
A 43 Junction Connector

B 45 Junction Connector
B 46 Junction Connector
B 47 Engine ECU
B 48 Engine ECU
B 49 Engine ECU
B 50 Engine ECU
B 60 4WD Control ECU


F 1 Accessory Meter
F 2 Clock
F 3 Tweeter (Front RH)
F 4 Tweeter (Front LH)
F 5 Junction Connector
F 6 Junction Connector

K 1 Airbag Sensor Assembly Center
K 11 Airbag Sensor Assembly Center


L 1 Airbag Sensor Assembly Center
L 7 4WD Control ECU (Rear Diff. Lock)
L 24 Airbag Sensor Assembly Center

Y 1 Airbag Squib (Front Passenger's Airbag Assembly)
Y 2 Airbag Squib (Front Passenger's Airbag Assembly)


A 1
White




A 2
Black




A 3
White




A 41
White




A 42
White




A 43
Gray




B 45
Blue




B 46
White




B 47
White




B 48
White




B 49
White




B 50
White




B 60
Black




F 1
White




F 2
Black




F 3
White




F 4
White




F 5
Blue




F 6
White




K 1
Yellow




K 11
Yellow




L 1
Yellow




L 7
White



L 24
Yellow



Y 1
Orange



Y 2
Black

