



Instrument Panel Wire Assembly
Roof Wire
Engine Wire
LA1
EA3
EA1
HE1
Front Door LH Wire
HE2
EA4
EL2
RE2
EL1
Floor No.2 Wire
EY1
BE3
BE2
BE1
EE3
EE1
Instrument Panel Wire
Instrument Panel No.2 Wire
Engine Room Main Wire
Front Door RH Wire
EA7
EA5
EA8
Floor No.2 Wire
RE3
LA2
Floor Wire
GE1
GE2
Floor Wire
EK1
EA6


BE1
White




BE2
White




BE3
White




EA1
Blue




EA3
Yellow




EA4
White





EA5
Yellow
EA6
Blue
EA7
White
EA8
Black
EE1
White
EE3
White
EK1
White
EL1
White
Gray
Gray


EL2
White




EY1
Yellow




GE1
White




GE2
White




HE1
White




HE2
White




LA1
White




LA2
White



RE2
White




RE3
White
1 2 3 4 5 6 7
8 9 10 11 12 13 14
7 6 5 4 3 2 1
14 13 12 11 10 9 8