

Combination Meter Assembly

The tachometer and the three (engine coolant, fuel, voltage) gauges are arranged to create a sense of individuality.




Models for Middle East

07D1MO08C




Models with Automatic Transmission for General Countries

07D0MO09C



Models with Manual Transmission for General Countries

07D0MO10C




07D1MO09C

Models for China

Accessory Meter (Except China)

The accessory meter with three additional gauges creates a rugged image.



Accessory Meter

0240MO15Z