

■ USB/AUX JACK

Instead of the previous AUX input jack, an USB/AUX jack is newly used on models with A750F automatic transmission for the Middle East and models for China, Australia and South Africa.

▶ System Diagram ◀



▶ Layout of Main Components ◀



LHD Models

07DNF420H