CRUISE CONTROL SYSTEM

■ DESCRIPTION

- When the system is set to a desired vehicle speed, the throttle valve position is adjusted automatically to maintain the vehicle speed without the driver having to depress the accelerator pedal.
- This system effects control through the ETCS-i (Electronic Throttle Control System-intelligent).
- This system is used as optional equipment on all models.

■ SYSTEM DIAGRAM

