
■CLUTCH START SYSTEM

1. General


The clutch start system prevents the starter from cranking unless the clutch pedal is depressed. The prevents the engine from being started in gear, and ensures safety by preventing the vehicle from moving unintentionally.


- A momentary type clutch start cancel switch is provided. This switch is always defaults to OFF every time the ignition switch is turned ON.
- When the clutch start cancel switch is pushed with the ignition switch ON, the clutch start system is canceled to allow starter motor operation without depressing the clutch pedal.

▶ System Diagram ◀



2. Layout of Main Components





0240CH65CS