■1GR-FE ENGINE

Cyclone Pre-cleaner Assembly

The cyclone pre-cleaner assembly consists of an air inlet, cleaner hose, and dust discharge valve. Dust is separated from the air at the air inlet, and is collected for disposal via the dust discharge valve inlet located on the cleaner hose periphery.

