






View A



View B





: Instrument Panel J/B Assembly

Cowl Side Panel LH**View C**

- * 1:10A ETCS (1GR-FE, 2TR-FE)
25A EFI-MAIN NO.1 (1GD-FTV, 2GD-FTV)
- * 2:25A EFI-MAIN NO.1 (1GR-FE, 2TR-FE, 1KD-FTV, 2KD-FTV, 5L-E)
25A EFI-MAIN NO.2 (1GD-FTV, 2GD-FTV)
- * 3:10A TAIL (1GR-FE, 2TR-FE, 1KD-FTV, 2KD-FTV, 5L-E)
10A ECU-ALT NO.2 (1GD-FTV, 2GD-FTV)
- * 4:10A ECU-ALT NO.2 (1GR-FE, 2TR-FE, 1KD-FTV, 2KD-FTV, 5L-E)
10A TAIL (1GD-FTV, 2GD-FTV)

