



Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)

G3	Headlight Dimmer Switch Assembly
G4	Spiral Cable Sub-Assembly
G5	Spiral Cable Sub-Assembly
G6	Blower Motor with Fan Sub-Assembly
G7	DLC3
G8	Combination Meter Assembly
G9	Combination Meter Assembly
G10	Combination Meter Assembly
G11	Transfer Position Switch
G12	No. 1 Power Outlet Socket Assembly
G16	Certification ECU
G17	Certification ECU
G19	Steering Lock Actuator or Upper Bracket Assembly
G20	Windshield Wiper Switch Assembly
G21	Windshield Wiper Switch Assembly
G22	Steering Sensor (Spiral Cable with Sensor Sub-Assembly)
G23	VSC Off Switch
G24	Downhill Assist Control Switch
G25	Smart Door Control Receiver Assembly
G27	Telltale Light Assembly
G28	No. 1 Indoor Electrical Key Antenna Assembly
G29	Cooler (Room Temperature Sensor) Thermistor
G33	Body ECU
G34	Body ECU
G35	Blower Motor Control
G36	A/C Control Assembly
G37	A/C Amplifier Assembly
G39	Headlight Leveling Switch
G129	Door Control Receiver
G131	A/C Amplifier Assembly
G177	Seat Heater Switch
G194	Refreshing Seat Switch RH
G197	A/C Amplifier Assembly


Position of Parts in Instrument Panel (LHD)




90980-12460




90980-12370




90980-12160




90980-11579




90980-11978




90980-12557




90980-12554




90980-12767




90980-11909




90980-12498




90980-12912



90980-12708




90980-12092




90980-12358


Position of Parts in Instrument Panel (LHD)




90980-12359




90980-12366




90980-12550




90980-12366




90980-12366




90980-12162




90980-12795




90980-11918




90980-12A45




90980-12A46




90980-10910




90980-12361




90980-12557




90980-11909




90980-12366



90980-12912




90980-11989



90980-12368

Position of Parts in Instrument Panel (LHD)



90980-12557