







Position of Parts in Instrument Panel (RHD)

- * 1: Refer to the Service Bulletin for the installation position of the parts.
- * 15: w/ Smart Entry & Start System
- * 16: w/o Smart Entry & Start System
- * 22: Before Aug. 2017 Production
- * 23: From Aug. 2017 Production



G93	No. 1 CAN Junction Connector
G94	No. 1 CAN Junction Connector
G95	No. 1 CAN Junction Connector
G96	No. 1 CAN Junction Connector
G97	No. 1 CAN Junction Connector
G98	No. 1 CAN Junction Connector
G99	No. 1 CAN Junction Connector
G106	No. 1 Blower Damper Servo Sub-Assembly
G110	No. 9 Junction Connector
G111	No. 10 Junction Connector
G112	No. 11 Junction Connector
G113	No. 12 Junction Connector
G114	No. 13 Junction Connector
G115	No. 14 Junction Connector
G116	No. 15 Junction Connector
G117	No. 16 Junction Connector
G118	No. 17 Junction Connector
G119	No. 18 Junction Connector
G120	No. 2 CAN Junction Connector
G121	No. 2 CAN Junction Connector
G122	No. 2 CAN Junction Connector
G123	No. 2 CAN Junction Connector
G125	No. 2 CAN Junction Connector
G126	No. 2 CAN Junction Connector
G127	Transponder Key ECU Assembly
G128	No. 2 CAN Junction Connector
G138	ID Code Box
G187	No. 48 Junction Connector

Position of Parts in Instrument Panel (RHD)



Position of Parts in Instrument Panel (RHD)

