


Position of Parts in Engine Compartment <RHD 1KD-FTV, 2KD-FTV>

- * 3:Before Aug. 2009 Production
- * 5:Before Aug. 2010 Production
- * 6:From Aug. 2010 Production
- * 7:Before Jun. 2011 Production
- * 8:From Jun. 2011 Production
- * 9:2WD A/T
- * 10:4WD, 2WD M/T
- * 11:1KD-FTV
- * 12:2KD-FTV
- * 13:1KD-FTV
From Aug. 2009
Production



- I 5 Injector Driver (EDU)
- I 6 Injector Driver (EDU)
- I 7 Inlet Air Temp. Sensor
- I 13 Inlet Air Temp. Sensor
- I 14 Injector Driver (EDU)
- I 15 Injector Driver (EDU)
- I 16 Injector Driver (EDU)
- I 17 Injector Driver (EDU)

- J 1 Junction Connector

- N 1 Park/Neutral Position SW
- N 4 Park/Neutral Position SW

- O 6 Option Connector (Engine Hood Courtesy SW)

- P 2 Pressure SW
- P 15 Pressure Discharge Valve

- R 1 Rear Washer Motor


- S 1 Security Horn
- S 2 Skid Control ECU with Actuator
- S 3 Speed Sensor
- S 4 Speed Sensor (Front LH)
- S 5 Speed Sensor (Front RH)
- S 6 Starter
- S 7 Starter
- S 8 Suction Control Valve
- S 9 Swirl Control Valve
- S 25 Skid Control ECU with Actuator
- S 29 Swirl Control Valve

- T 2 Throttle Body Assembly
- T 3 Throttle Body Assembly
- T 4 Transfer Indicator SW (Center Diff. Lock)
- T 5 Transfer Indicator SW (L4 Position)
- T 6 Transfer Indicator SW (Neutral Position)
- T 7 Transmission Revolution Sensor (Input)
- T 8 Transmission Revolution Sensor (Output)
- T 9 Turbo Pressure Sensor
- T 10 Turbocharger Variable Nozzle Motor
- T 11 Turbocharger Variable Nozzle Sensor
- T 12 Turn Signal Lamp (Front LH)
- T 13 Turn Signal Lamp (Front RH)
- T 14 Turn Signal Lamp (Front Side LH)
- T 15 Turn Signal Lamp (Front Side RH)

- V 1 VRV (EGR)
- V 2 VSV (EGR Cut Valve)
- V 7 VRV (EGR)

- W 1 Water Temp. Sensor
- W 2 Windshield Washer Motor
- W 3 Windshield Wiper Motor

Position of Parts in Engine Compartment <RHD 1KD-FTV, 2KD-FTV>



Position of Parts in Engine Compartment <RHD 1KD-FTV, 2KD-FTV>

