


- \* 1:A/T
- \* 2:M/T
- \* 5:Before Jun. 2011 Production
- \* 6:From Jun. 2011 Production



H 1 Headlamp (LH High)  
H 2 Headlamp (LH Low)  
H 2 Headlamp (LH Low)  
H 3 Headlamp (RH High)  
H 4 Headlamp (RH Low)  
H 4 Headlamp (RH Low)  
H 6 Horn (High)  
H 7 Horn (Low)  
H 12 Heated Oxygen Sensor (Bank 1 Sensor 2)  
H 13 Heated Oxygen Sensor (Bank 2 Sensor 2)  
H 13 Heated Oxygen Sensor (Bank 2 Sensor 2)  
H 18 Headlight Cleaner Motor and Pump Assembly  
H 19 Headlight Cleaner Control Relay  
H 20 Headlamp (RH Low)  
H 21 Headlamp (LH Low)  
H 22 Headlamp Leveling Motor (RH)  
H 23 Headlamp Leveling Motor (LH)

I 1 Ignition Coil (No.1)  
I 2 Ignition Coil (No.2)  
I 3 Ignition Coil (No.3)  
I 4 Ignition Coil (No.4)  
I 10 Ignition Coil (No.5)  
I 11 Ignition Coil (No.6)

Position of Parts in Engine Compartment <RHD 1GR-FE>

