


* 1:Before Jun. 2011 Production

* 2:From Jun. 2011 Production



- J 1 Junction Connector
- M 3 Manifold Absolute Pressure Sensor
- P 2 Pressure SW
- R 1 Rear Washer Motor
- S 2 Skid Control ECU with Actuator
- S 3 Speed Sensor
- S 4 Speed Sensor (Front LH)
- S 5 Speed Sensor (Front RH)
- S 6 Starter
- S 7 Starter
- S 24 Spill Control Valve
- T 4 Transfer Indicator SW (Center Diff. Lock)
- T 5 Transfer Indicator SW (L4 Position)
- T 12 Turn Signal Lamp (Front LH)
- T 13 Turn Signal Lamp (Front RH)
- T 14 Turn Signal Lamp (Front Side LH)
- T 15 Turn Signal Lamp (Front Side RH)
- T 31 Throttle Body Assembly
- T 32 Throttle Position SW
- T 33 Timing Control Valve
- W 1 Water Temp. Sensor
- W 2 Windshield Washer Motor
- W 3 Windshield Wiper Motor

Position of Parts in Engine Compartment <LHD 5L-E>

