


























- * 9:2TR-FE From Aug. 2008 Production,
5L-E From Aug. 2008 Production
- * 10:Except *9
- * 14:Before Jun. 2011 Production
- * 15:From Jun. 2011 Production
- * 22:Radio & Display Receiver Type
- * 23:Radio Receiver Type
- * 35:Before Aug. 2013 Production
- * 36:From Aug. 2013 Production
- * 37:*22 *35 *39
- * 38:*22 *36 *39



* 39:w/ No. 1 Stereo Jack Adapter Assembly
* 40:*23 *39

K	2	Key Interlock Solenoid
L	1	Light Control Rheostat , Short Connector (Light Control Rheostat)
M	1	Magnet-Clutch Relay
M	5	Magnet-Clutch Relay
N	3	No.1 Stereo Jack Adapter Assembly
N	5	No.1 Stereo Jack Adapter Assembly
O	1	Outer Mirror SW
P	3	Parking Brake SW
P	4	Power Outlet Socket (Front)
P	14	Passenger Seat Belt Warning Lamp
P	16	Passenger Seat Belt Warning Lamp
R	2	Radio Receiver Assembly
R	3	Radio Receiver Assembly
R	4	Radio Receiver Assembly
R	5	Rear Window Defogger SW
R	19	Radio & Display Receiver Assembly
R	20	Radio & Display Receiver Assembly
R	23	Rear Window Defogger SW
R	24	Radio & Display Receiver Assembly
R	25	Radio & Display Receiver Assembly
R	26	Radio & Display Receiver Assembly
R	27	Radio Receiver Assembly
R	28	Radio Receiver Assembly
R	31	Radio & Display Receiver Assembly
R	32	Radio & Display Receiver Assembly

Position of Parts in Instrument Panel <LHD>



R 32

Gray

