




- A 14 A/C Amplifier
- A 15 A/C Control Assembly
- A 16 A/C Control Assembly
- A 17 A/C Room Temp. Sensor
- A 18 A/C Solar Sensor
- A 19 A/C Thermistor
- A 21 A/T Shift Lever Illumination
- A 22 Accelerator Position Sensor
- A 23 Accessory Meter
- A 24 Airbag Sensor Assembly Center
- A 25 Airbag Squib (Front Passenger's Airbag Assembly)
- A 26 Airbag Squib (Steering Wheel Pad)
- A 27 Antenna Amplifier
- A 28 Ashtray Illumination
- A 32 A/C SW
- A 33 Airbag Sensor Assembly Center
- A 34 Airbag Sensor Assembly Center
- A 36 A/T Shift Lever Illumination
- A 37 A/C Control Assembly
- A 38 A/C Control Assembly
- A 39 Automatic Light Control Sensor
- A 40 A/C SW
- A 41 A/C Room Temp. Sensor
- A 42 A/C Solar Sensor
- A 43 Accessory Meter

Position of Parts in Instrument Panel <RHD>

