

FRONT STEP LOWER PANEL (ASSY)




F20535A

REPLACEMENT

REMOVAL





F20535

POINT


1 Remove the [A] at the same time.

PART NAME

[A] Front Body Outer Pillar

INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.



F20536

PART NAME

[A] Front Body Outer Pillar [B] Front Bumper Side Retainer