
SAFETY

SRS Airbag System

- An SRS (Supplementary Restraint System) driver airbag and SRS driver and front passenger airbags are provided. The provision of the SRS airbag system varies by destination. For details, see page MO-40 in Equipment List.
- The SRS airbag helps reduce the shocks to the head and chests of the driver*1 and passenger*2 in the event of severe frontal impact collision as supplements to the seat belts.



286BE33

LHD Model

*1: Only for Model with Driver SRS Airbags
*2: Only for Model with Driver and Passenger SRS Airbags