
■SEAT BELT REMINDER SYSTEM

General

On the new Thailand automatic transmission models, the seat belt reminder system warns the driver by sounding the buzzer, instead of warning them by illuminating the seat belt reminder light.

- When the ignition switch is turned on, this system detects the condition of the seat belts based on the signals from the seat belt buckle switches (for the driver and front passenger) and the occupant detection sensor.
- The buzzer sounds when the vehicle speed exceeds approx. 20 km/h (12.4 mph) to emphasize the fact that the seat belt is unbuckled. After approx. 30 seconds, this sound changed to emphasize. This sound sounds during approx. 90 seconds. Once a buzzer begins to sound, it will continue until the seat belt is buckled or the ignition switch is turned off.

▶ System Diagram ◀



04Z1HA21Y