
■ FUEL INJECTION VOLUME CONTROL

1. Function


The ECM calculates 2 types of values: the basic injection volume and the maximum injection volume. Then, the ECM compares the basic and maximum injection volumes, and determines the smaller calculated value to be the final injection volume.

► Basic Injection Volume ◄




26T4EG29

► Maximum Injection Volume ◄



26T4EG30

► Final Injection Volume Decision ◄



26T4EG31