■ SWIRL CONTROL

1. Construction

The ECM controls the swirl control valve position to optimize exhaust emissions.

