
■ DPF

1. Construction

A DPF catalyst is used to collect and purify PM.



26T4EG83

Text in Illustration

*1	Exhaust Manifold Converter Sub-assembly	*2	DPF
26T4EG98	Exhaust Gas	-	-