
■ NOX SENSOR

1. Construction

A NOx sensor (nitrogen oxides sensor) is installed in center exhaust pipe assembly, in order to detect the concentration of NOx in the exhaust gas.



26T4EG13D

Text in Illustration

*1	NOx Sensor (Nitrogen Oxides Sensor)	-	-