



Cruise Control (2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production) and Engine Control (1TR-FE, 2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production)

M OVERALL ELECTRICAL WIRING DIAGRAM

HIACE (EM26T4E)




Cruise Control (2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production) and Engine Control (1TR-FE, 2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production)



HIACE (EM26T4E)

Cruise Control (2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production) and Engine Control (1TR-FE, 2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production)



*4 : RHD
*5 : LHD
*21 : Before Jan. 2017 Production
*22 : From Jan. 2017 Production

Cruise Control (2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production) and Engine Control (1TR-FE, 2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production)


13

14

15

16

HIACE (EM26T4E)



Cruise Control (2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production) and Engine Control (1TR-FE, 2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production)


17

18

19

20

*1 : w/ Cruise Control System
*20 : w/ Engine Immobiliser System



Engine Immobiliser System (1TR-FE, 2TR-FE) (w/ Dual VVT-i) (From Jan. 2015 Production)

HIACE (EM26T4E)

