




- D 64 Pressure Discharge Valve
- D 65 Turbocharger Variable Nozzle Motor Assembly
- D 66 Turbocharger Variable Nozzle Motor Assembly
- D 67 Swirl Control Valve
- D 68 VSV (EGR Cut)
- D 69 Fuel Pressure Sensor
- D 70 Engine ECU
- D 71 Engine ECU
- D 72 Crankshaft Position Sensor
- D 73 VRV (EGR)
- D 74 VSV (EGR)
- D 75 Engine ECU
- D 76 Engine ECU
- D 79 Crankshaft Position Sensor
- D 81 Fuel Injector Assembly (No.1)
- D 82 Fuel Injector Assembly (No.2)
- D 83 Fuel Injector Assembly (No.3)
- D 84 Fuel Injector Assembly (No.4)
- D 85 A/T Fluid Temp. Sensor
- D 87 Pressure Discharge Valve
- D 88 Glow Plug
- D 89 Oil Pressure Switching Valve Assembly
- D 91 Suction Control Valve Assembly
- D 92 Exhaust Fuel Addition Injector Assembly
- D 93 Oil Pressure Sender Gage Assembly












- E 1 Starter
- E 1 Starter
- E 1 Starter
- E 2 Starter

- m 1 Cooling Fan ECU No.1 , Cooling Fan Motor No.1
- m 2 Cooling Fan ECU No.2 , Cooling Fan Motor No.1

- s 1 Electric EGR Control Valve Assembly


- t 1 Diesel Throttle Body Assembly

Position of Parts in Engine Compartment <RHD 1KD-FTV, 2KD-FTV>




Position of Parts in Engine Compartment <RHD 1KD-FTV, 2KD-FTV>


D 82
Gray



D 83
Black




D 84
Gray



D 85
Black




D 87
Gray




D 88
Black



D 89
Black



D 91
Brown




D 92
Black



D 93
Black



E 1




(2KD-FTV A/T Except Cold Area Spec.)

E 1



(1KD-FTV Russia, 2KD-FTV Cold Area Spec.)

E 1




(1KD-FTV Except Russia, 2KD-FTV M/T Except South Africa Production Except Cold Area Spec.)

E 2
Black




(1KD-FTV, 2KD-FTV, 5L-E)


m 1
Gray



m 2
Black



s 1
Black



t 1
Black

