


Position of Parts in Body <LHD>



- T 5 Map Lamp
- T 6 Diode (Door Courtesy No.4)
- T 8 Room Lamp (Center)
- T 9 Diode (Door Courtesy No.5)
- T 13 Room Lamp (Rear)
- T 16 Rear Combination Lamp (LH)
- T 22 Room Lamp (Front)
- T 23 Room Lamp (Rear)
- T 24 Room Lamp (Center)
- T 25 Junction Connector
- T 26 Speaker (Roof LH)
- T 27 Speaker (Roof RH)
- T 28 Hammer Buzzer (Buzzer Assembly)
- T 29 Front Hammer Switch LH
- T 30 Rear Hammer Switch LH
- T 32 Room Lamp (Luggage compartment)
- T 33 Rear Combination Lamp (RH)
- T 34 Rear Hammer Switch RH
- T 35 Junction Connector
- T 36 Room Lamp (Rear)
- T 37 Room Lamp (Center)

- U 1 Rear Combination Lamp (RH)
- U 3 Rear Hammer Switch RH
- U 4 Junction Connector

- X 2 Door Courtesy SW (Slide Door RH)
- X 3 Speaker (Rear RH)

- Y 2 Door Control Receiver
- Y 3 Door Courtesy SW (Slide Door LH)
- Y 5 Speaker (Rear LH)

- a 2 Back Door Courtesy SW
- a 3 Back Door Lock Assembly
- a 4 License Plate Lamp
- a 5 Television Camera Assembly
- a 6 Back Door Lock Assembly
- a 7 Back Door Lock Assembly (Door Control Switch)
- a 8 Back Door Closer Relay
- a 9 Back Door Closer Motor Assembly
- a 11 Interior Illumination Lamp Sub-Assembly

- b 1 Rear Window Defogger
- b 2 Rear Window Defogger

- d 1 Center Stop Lamp
- d 3 Rear Wiper Motor
- d 4 Rear Hammer Switch (Back Door)

Position of Parts in Body <LHD>



Position of Parts in Body <LHD>

