












Position of Parts in Instrument Panel <RHD>



- A 30 Daytime Running Light (Headlamp Assembly LH)
- A 31 Junction Connector
- A 33 Headlamp Assembly RH
- A 34 Headlamp Assembly RH
- A 35 Headlamp Leveling Motor (RH)
- A 36 Headlamp Assembly LH
- A 37 Headlamp Assembly LH
- A 38 Headlamp Leveling Motor (LH)
- A 39 Headlamp Leveling Computer Assembly
- A 40 Indoor Electrical Key Antenna Assembly (FR RH)
- A 41 Indoor Electrical Key Antenna Assembly (FR LH)
- A 42 Wireless Door Lock Buzzer
- A 43 Brake Vacuum Warning SW
- A 44 Ambient Temp. Sensor
- A 45 Urea Pump Control ECU
- A 46 Urea Tube with Heater Assembly
- A 47 Urea Pump
- A 49 Junction Connector
- A 50 Air Flow Meter

Position of Parts in Instrument Panel <RHD>



(From Jan. 2017 Production)

