
Position of Parts in Body



P 5 Power Window Master SW with ECU
P 6 Power Window Motor Front LH
P 7 Power Window Motor Front RH
P 8 Power Window Motor Rear LH
P 9 Power Window Motor Rear RH
P10 Power Window SW Front LH
P11 Power Window SW Rear LH
P12 Power Window SW Rear RH
P13 Pretensioner LH
P14 Pretensioner RH

R 8 Rear Combination Light LH
R 9 Rear Combination Light RH
R10 Rear Door Speaker LH
R11 Rear Door Speaker RH
R12 Rear Heater Blower Motor
R13 Rear Heater Blower SW
R14 Rear Heater Relay
R15 Rear Interior Light
R16 Rear Interior Light SW
R17 Rear Power Outlet
R18 Rear Window Defogger
R19 Rear Window Defogger
R20 Rear Wiper Motor
R21 Remote Control Mirror LH
R22 Remote Control Mirror RH

S14 Side Airbag Sensor Front LH
S15 Side Airbag Sensor Front RH
S16 Side Airbag Sensor Rear LH
S17 Side Airbag Sensor Rear RH
S18 Side Airbag Squib LH
S19 Side Airbag Squib RH
S20 Sliding Roof Control ECU

T 9 Tweeter LH
T10 Tweeter RH

V 7 Vanity Light LH
V 8 Vanity Light RH

W 5 Wireless Door Lock ECU

Y 1 Yaw Rate Sensor