
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
BA1	Rear Door No.1 LH Wire and Floor No.2 Wire (Left Center Pillar)
BB1	Rear Door No.1 RH Wire and Floor Wire (Right Center Pillar)
BC1	Back Door No.1 Wire and Floor No.2 Wire (Rear Left of Roof)
BC2	
BC3	
BD1	Floor No.2 Wire and Floor Wire (Near the Rear Side Marker Light RH)