

From Power Source System (See Page 56)
7. 5A
IG1
2
1G
R
10
II1
R
2
A 3
Back–Up Light SW
1
R–B
20
II1
L
6
4A
3
4I
P
10
IA3
P
C
J11
Junction
Connector
C
C
P
P
P
1
1
Back–Up
R 9
Rear Combination
Light RH
Back–Up
R 8
Rear Combination
Light LH
6
6
W–B
W–B
B
B
J11
Junction
Connector
B
W–B
BC