

TAILLIGHT Relay
10A TAIL
1A
1J
1B
1B
1H
SB
W
IA4
B 4(A), B 5(B) Body ECU
TRLY
TAIL
BR
J12 Junction Connector
V
G
G
Light Control SW
OFF
Tail
Head
C10 Combination SW
B
W–B
W–B
W–B
W–B
W–B
W–B
BR
BR
BR
BC3
W
F 1 Front Clearance Light LH
F 2 Front Clearance Light RH
R 8 Rear Combination Light LH
R 9 Rear Combination Light RH
L 1 License Plate light
Tail
Tail
140A ALT
F11 Fusible Link Block
FL MAIN 3. 0W
Battery
J11 Junction Connector
J 1 Junction Connector
J 4 Junction Connector
J13 Junction Connector
IC
EE
EA
BC
BD