

(Cont. next page)
13 KLUGER
ABS
Power Source
A31
ABS Deceleration Sensor
(Shielded)
S 9(A), S10(B), S11(C)
Skid Control ECU
DLC3<2–12><2–18>
A 4
ABS Actuator
Under the Left
Headlight
10A HEATER
10A ECU–IG
7. 5A ABS3
ABS SOL
Relay
ABS MTR
Relay
I13
Ignition SW
F11
Fusible Link Block
40A ABS2
40A ABS1
30A AM2
140A ALT
40A AM1
FL MAIN
3. 0W
Battery

13 KLUGER (Cont' d)

