

Power Outlet
Cigarette Lighter
Power Source
1
2
3
4
R17
Rear Power
Outlet
J11
Junction
Connector
Near the Rear Side
Marker Light LH
P 4
Power Outlet
(Front)
C 6
Cigarette
Lighter
Left Instrument
Panel Brace
15A CIG
ACC
Relay
Right Cowl
Side Panel
15A
PWR OUTLET1
40A AM1
I13
Ignition SW
ACC
IG1
ST1
AM1
F11
Fusible Link
Block
140A ALT
FL MAIN
3.0W
Battery
Y
V
W–B
LG
G
P
L
W
B

25 KLUGER