■ILLUMINATED ENTRY SYSTEM

- When a door is unlocked through a key operation or transmitter operation, or if a door is opened, the illuminated entry system turns ON the interior light and the ignition key illumination.
- If the ignition switch is turned to the ACC or ON position, or if all doors are closed during the 15 seconds in which these lights are ON, they will be immediately OFF.
- This system is controlled by the Body ECU.

▶ System Diagram ◀

