DOOR LOCK CONTROL SYSTEM

■ DESCRIPTION

The door lock control system in the new Kluger has the following functions:

Function	Outline
Manual Lock and Unlock Function	This function can lock or unlock all the doors by the door lock control switch operation.
Key-linked Lock and Unlock Function	This function, which is linked with the key cylinder, can lock or unlock all the doors when a lock or unlock operation is effected.
Key Confine Prevention Function	When the key is inserted in the ignition key cylinder with the driver's door open and if you perform the door lock operation, all the doors will be unlocked.
Manual Unlock Prohibition Function*	Performing the door lock operation with a transmitter or an ignition key will prohibit the unlock operation by the door lock control switch.

*: The setting of function can be changed by using the customized body electronics system. For details, refer to the Customized Body Electronics System section on page BE-17.

▶ System Diagram ◀

