
















DIFFERENTIAL










PREPARATION

023PO–01




SST

	09223–00010	Cover & Seal Replacer	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09308–00010	Oil Seal Puller	REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09308–10010	Oil Seal Puller	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09316–12010	Transfer Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09325–20010	Transmission Oil Plug	REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09330–00021	Companion Flange Holding Tool	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09370–50010	Drive Line Angle Gauge	REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09504–22011	Differential Side Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09506–30012	Differential Drive Pinion Rear Bearing Cone Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09550–00032	Replacer	REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09554–22010	Differential Oil Seal Replacer	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09556–22010	Drive Pinion Front Bearing Remover	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)

	09570–24010	Differential Mounting Cushion Remover & Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09636–20010	Upper Ball Joint Dust Cover Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09930–00010	Drive Shaft Nut Chisel	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09950–00020	Bearing Remover	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09950–30012	Puller A Set	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09951–03010)	Upper Plate	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09953–03010)	Center Bolt	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09954–03010)	Arm	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09955–03030)	Lower Plate 130	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09956–03020)	Adapter 18	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09950–40011	Puller B Set	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09951–04020)	Hanger 200	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09952–04010)	Slide Arm	DIFFERENTIAL CARRIER ASSY REAR(4WD)

	(09953–04030)	Center Bolt 200	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09954–04010)	Arm 25	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09955–04061)	Claw No.6	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09957–04010)	Attachment	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09958–04011)	Holder	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09950–60010	Replacer Set	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09951–00360)	Replacer 36	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09951–00620)	Replacer 62	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09950–60020	Replacer Set No.2	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09951–00710)	Replacer 71	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09950–70010	Handle Set	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09951–07150)	Handle 150	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09951–07200)	Handle 200	REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)

Recomended Tools

	09011–12301	Socket Wrench 30 mm	REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09025–00010	Torque Wrench (30 kgf–cm)	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09040–00011	Hexagon Wrench Set	REAR DIFFERENTIAL CARRIER OIL SEAL(4WD) REAR DIFFERENTIAL SIDE GEAR SHAFT SEAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)

Equipment

Dial indicator	
Torque wrench	
Alignment tester	
Toe–in gauge	
Deep socket wrench 24 mm	

Lubricant

Item	Capacity	Classification
Differential oil	0.90 ± 0.05 liters (0.95 ± 0.05 US qts, 0.75 ± 0.04 Imp.qts)	Hypoid gear oil API GL–5 Above –18°C (0°F) SAE 90 Below –18°C (0°F) SAE 80W or 80W–90

SSM

	08826–00090	"Seal Packing 1281," THREE BOND 1281 or equivalent (FIPG)	