






BRAKE


PREPARATION

023GY–01

SST

	09023–00100	Union Nut Wrench 10 mm	BRAKE FLUID BRAKE MASTER W/PLATE CYLINDER SUB–ASSY BRAKE BOOSTER ASSY FRONT BRAKE REAR BRAKE BRAKE ACTUATOR ASSY(W/ VSC) BRAKE ACTUATOR ASSY(W/O VSC)
	09737–00020	Brake Booster Push Rod Wrench	BRAKE MASTER W/PLATE CYLINDER SUB–ASSY BRAKE BOOSTER ASSY
	09950–50013	Puller C Set	STEERING SENSOR
	(09951–05010)	Hanger 150	STEERING SENSOR
	(09952–05010)	Slide Arm	STEERING SENSOR
	(09953–05020)	Center Bolt 150	STEERING SENSOR
	(09954–05021)	Claw No.2	STEERING SENSOR

Recomended Tools

	09042–00010	Torx Socket T30	STEERING SENSOR
	09070–20010	Moulding Remover	BRAKE PEDAL SUB–ASSY

Equipment

Dial indicator with magnetic base	
Micrometer	
Torque wrench	
Slide calipers	

Lubricant

Item	Capacity	Classification
Brake fluid	–	SAE J1703 or FMVSS No. 116 DOT3